

PRODUCT INFORMATION SHEET

These items were imported by: -
Just 1 Source & Supply Limited, Barton Hill, Whitwell, York. YO60 7JX
Telephone: 01653 617718 - www.just1source.com

These items comply with the requirements of the EU Regulation 2016/425, in line with the harmonised standard(s) referenced below.

NOTE: - Declarations of Conformity can be found at www.just1source.com

Limitations of use:

EN 388:2016 + A1:2018, EN ISO 21420:2020 - The overall classification of gloves with two or more layers does not necessarily reflect the performance of the outermost layer. Gloves should not be worn when there is a risk of entanglement by moving parts or machinery.

The EN 388 test results shown below are taken from the palm area of the glove.

EN 388:2016 + A1:2018



4131A

EN ISO 21420:2020



Test	Performance Level
EN 388:2016 + A1:2018	
Abrasion	4 (Scale 1-4)
Blade Cut (Coup Test)	1 (Scale 1-5)
Tear	3 (Scale 1-4)
Puncture	1 (Scale 1-4)
ISO 13997 Cut (TDM)	A (Scale A-F)
Impact Protection	(P if passed)

ISO Cut Level	A	B	C	D	E	F
Newtons	≥2	≥5	≥10	≥15	≥22	≥30

Performance levels are measured where the highest number indicates the best protection. "X" indicates that the product has not been tested against this risk

Product Code: - **NSPL** Size: 7 - 11
Product Name: - **PRED Scarlet**
Product Description: - Red Polyester Liner; Smooth Nitrile Palm Coated

Gloves providing protection against mechanical risks.

Maintenance: examine gloves for damages, splits and holes before each use. Always replace damaged gloves.

Disposal – Dispose of used gloves as instructed by your local authority

Sizing & Fitting: Only wear products of a suitable size, if a product is either too loose or too tight will restrict movement and will not provide the optimum level of protection. Ensure donning and doffing is completed correctly to prevent contamination of the hand.

Donning-Insert all five fingers into the cuff of the glove and pull the cuff over your wrist until the glove is properly in place. Make sure the cuff is pulled up fully to avoid any substances or debris entering the glove.

Doffing- Pinch and lift the outside of the glove in the palm area with the opposite gloved hand; peel off while turning inside out. Hold the removed glove in the gloved hand. Slide two fingers of the ungloved hand under the remaining glove at the wrist. Peel the second glove off over the first glove and discard.

STORAGE: Store in dry ambient conditions

AFTERCARE: No Cleaning Treatment



EU Type Certification issued by **SATRA Technology Europe Ltd**, Bracetown Business Park, Clonee, Dublin 15, Ireland - **Notified Body 2777**